

Part Numbers for Ordering

Model Series 4LSF Standard Popular Split Current Transformers

333mV shown but can be substituted with millivolt outputs

from 50mV to 1000mV or milliamps from 50mA to 333mA.



Window		Window		Window	
1.25X2.0	333mV Out	3.0X3.0	333mV Out	4.0X6.0	333mV Out
4LSF-400A:333mV-1.25X2.0		4LSF-200A:333mV-3.0X3.0		4LSF-2000A:333mV-4.0X6.0	
		4LSF-800A:333mV-3.0X3.0		4LSF-2500A:333mV-4.0X6.0	
1.5X2.0	333mV Out	4LSF-1000A:333mV-3.0X3.0		4LSF-3000A:333mV-4X6	
4LSF-600A:333mv-1.5X2.0		4LSF-2400A:333mV-2.0X3.0			
				5.0X5.0	333mV Out
1.5X3.5	333mV Out	3.0X3.5	333mV Out	4LSF-400A:333mV-5X5	
4LSF-600A:333mV-1.5X3.5		4LSF-800A:333mV-3.0X3.5		4LSF-1600A:333mV-5X5	
4LSF-800A:333mV-1.5X3.5				4LSF-1800A:333mV-5X5	
		3.0X4.0	333mV Out	4LSF-2000A:333mV-5X5	
1.5X4.0	333mV Out	4LSF-1600A:333mV-3.0X4.0		4LSF-2500A:333mV-5X5	
4LSF-800:333mV-1.5X4.0				4LSF-3000A:333mV-5X5	
4LSF-2000A:333mV-1.5X4.0		3.0X7.0	333mV Out		
		4LSF-4000A:333mV-3X7		5.0X7.0	333mV Out
2.0X2.0	333mV Out			4LSF-800A:333mV 5.0X7.0	
4LSF-100A:333mV-2.0X2.0		4.0X4.0	333mV Out	4LSF-1000A:333mV 5.0X7.0	
4LSF-200A:333mV-2.0X2.0		4LSF-400A:333mV-4.0X4.0		4LSF-2000:333mV-5.0X7.0	
4LSF-300A:333mV-2.0X2.0		4LSF-500A:333mV-4.0X4.0		4LSF-3000A:333mV-5.0X7.0	
4LSF-600A:333mV-2.0X2.0		4LSF-600A:333mV-4.0X4.0		4LSF-4000A:333mV-5.0X7.0	
		4LSF-800A:333mV-4.0X4.0		4LSF-5000A:333mV-5.0X7.0	
2.0x3.0	333mV Out	4LSF-1000A:333mV-4.0X4.0		4LSF-6000A:333mV-5.0X7.0	
4LSF-200A:333mV-2.0X3.0		4LSF-1200A:333mV-4.0X4.0			
4LSF-300A:333mV-2.0X3.0		4LSF-1600A:333mV-4.0X4.0		5.0X8.0	333mV Out
4LSF-400A:333mV-2.0X3.0		4LSF-2000A:333mV-4.0X4.0		4LS-3000A:333mV-5.0X8.0	
4LSF-500A:333mV-2.0X3.0					
4LSF-600A:333mV-2.0X3.0		4.0X4.5	333mV Out	6.0X6.0	333mV Out
4LSF-800A:333mV-2.0X3.0		4LSF-400A:333mV-4.0X4.5		4LS-1600A:333mV-6.0X6.0	
4LSF-1000A:333mV-2.0X3.0		4LSF-600A:333mV-4.0X4.5		4LSF-3000A:333mV-6X6	
4LSF-1500A:250mV-2.0X3.0		4LSF-800A:333mV-4.0X4.5			
		4LSF-1000A:333mV-4.0X4.5		6.0X8.0	333mV Out
2.5x2.5	333mV Out	4LSF-1200A:333mV-4.0X4.5		4LS-1200A:333mV6.0X8.0	
4LSF-200A:333mV-2.5X2.5		4LSF-1500A:333mV-4.0X4.5		4LSF-2400A:333mV-6.0X8.0	
4LSF-600A:333mV-2.5X2.5		4LSF-2000A:333mV-4.0X4.5		4LSF-3000A:333mV-6.0X8.0	
4LSF-800A:333mV-2.5X2.5		4LSF-3000A:333mV-4.0X4.5		4LSF-4000A:333mV-6.0X8.0	
4LSF-1000A:333mV-2.5X2.5		4LSF-4000A:333mV-4.0X4.5		4LSF-6000A:333mV-6.0X8.0	