



SPECTRUM INDUSTRIES, INC.

461 BOSTON STREET, UNIT E6, TOPSFIELD, MA 01983

PH:1-800-644-9773/978-887-2020

meters@spectrumind.com

ZIG ZAG TRANSFORMERS FOR NEUTRAL GROUNDING



Protect your photovoltaic system from damaging fault currents by using lower cost zig zag transformers to derive a neutral for grounding purposes.

Capabilities

- Power up to 1000kVA
- Up to 25kV Class/150 kV BIL
- Three Phase Zig-Zag Transformer
- Current Transformer Metering
- Dry Type – Copper or Aluminum Windings
- VPI (Vacuum-Pressure Impregnation varnish with gas-fired oven curing)
- Insulation Class 150, 180 and 220 available
- Custom Impedance/ Current/ X/R Ratio

Optional

- NEMA 1 or NEMA 3R enclosure
- Thermal Switches
- Custom Terminations
- Issue of Certificate of Compliance and Test Reports
- Air terminal chamber for maintaining proper clearance between coil and grounding wire, and providing for quicker and more secure installation

HAVE OUR ENGINEERS DESIGN YOUR CUSTOM TRANSFORMER SOLUTION TODAY