

MODELS OFFERED**TW-12:** Single Phase, 2 Wire – 1 Element**TW-13:** Single Phase, 3 Wire – 2 Element**TW-33:** 3 Phase, 3 Wire – 2 Element**TW-34:** 3 Phase, 4 Wire – 3 ElementABS DIN RAIL MOUNT CASE **D**SCREW MOUNT METAL CASE **B**

- Accurate measurement of the active power Watts for balanced or unbalanced loads.
- The output signals are isolated load independent DC mA or DC Volts, representing the measured value of the active power Watts.

FEATURES

- Uses Time Division Multiplication (TDM) for precision measurement of even distorted signals.
- High accuracy $\pm 0.2\%$ of Rated Output (R.O.)
- Super high accuracy $\pm 0.1\%$ of Rated Output (R.O.) available as a special order.*
- High immunity to external noise.
- Quick and easy mounting to 35mm DIN Rail (DIN46277) or screw mounting.
- Many input and output signal combinations

GENERAL SPECIFICATIONS

Accuracy	$\pm 0.2\%$ R.O. Standard for 10 to 100% of rated output $\pm 0.1\%$ R.O. (Special Option)
Temp. coefficient	$\leq 100\text{ppm}/^\circ\text{C}$ of span $\leq 60\text{ppm}/^\circ\text{C}$ for ambient temperature of $25^\circ\text{C} \pm 10^\circ\text{C}$
Temp. range	Storage temperature range -20°C to 60°C (-4°F to 140°F) Operating temperature range 0°C to 50°C (32°F to 122°F)
Humidity range	Up to 95% RH non condensing
Isolation	Between Input/Output/Power/Case
Dielectric test	DIN-IEC 688 2K Vrms/1 min, Between terminal to terminal 2.8K Vrms/1 min, Between terminal to case
Surge test	DIN-IEC 255-4, ANSI C37 90a/1974 5KV($1.2 \times 50 \mu\text{s}$)
Insulation Resistance	Greater than 100 M Ω at 500V DC
Housing material	ABS Resin(94V-0) or metal
Mounting	Screw mount on metal case or Plastic case DIN Rail 35mm
Auxiliary Power	AC 115/230V $\pm 15\%$, 50/60Hz, 3VA DC 24V $\pm 20\%$ (optional) 125V DC $\pm 20\%$ (optional)

INPUT SPECIFICATIONS

AC Input	120V/5A AC, 240V/5A AC for 1 ϕ /2 wire, 240V/120V, 5A AC for 1 ϕ /3 Wire 120V/5A AC, 240V/5A AC for 3 ϕ /3 Wire & 3 ϕ /4 Wire custom input (600V max /10A AC max)
Frequency	60Hz $\pm$ 3Hz, 50Hz $\pm$ 3Hz, 400Hz $\pm$ 3Hz
Burden	$\leq$ 0.2VA per current circuit, $\leq$ 0.1VA per voltage circuit.
Response Sensitivity	$\leq$ 0.5% of measuring range to maximum input range
Input Voltage	600V AC rms continuous (absolute maximum)
Overload Capacity	1.25 times the rated input Voltage continuously. 2 times the rated input Voltage for 10 secs. 4 times the rated input Voltage for 5 secs.
Input Current	3 times the rated input current continuously.
Overload Capacity	10 times the rated input current for 10 secs. 50 times the rated input current for 1 sec. 80 times the rated input current for 0.5 secs

OUTPUT SPECIFICATIONS

Output Variables	DC mA or DC Volts
Ripple	< 0.5% of rated output. Peak to Peak (maximum)
Response Time	< 400 milliseconds to go from 0 to 99% of output
Zero Adjustment	$\pm$ 5% of rated output (minimum)
Span Adjustment	$\pm$ 10% of rated output (minimum)
Load Resistance	10 k Ω maximum for 0 to 1mA output 500 Ω maximum for 4 to 20mA output 500 Ω minimum for 0 to 10V output

Maximum Input range value = (CT Ratio) X (PT Ratio) X (Nominal Watts)

If CT = 200A:5A

PT is 3300V:110V

Nominal Watts = 500

then CT Ratio = 40 then PT Ratio = 30 and Maximum input range value = 40 x 30 x 500 = 600KW

CONNECTION DIAGRAM

